



# Warwick Powerflue

**DECORATIVE FUEL EFFECT POWERFLUE GAS  
FIRE**

**Installation & Maintenance Instructions**

**Hand these instructions to the user**

**Model No. FCPC14MN & FCPC26MN is for use on Natural Gas (G20)  
at a supply pressure of 20 mbar in G.B. / I.E.**

# CONTENTS

<b>Section 1</b>	<b>Information and Requirements</b>	<b>PAGE</b>
1.0	Appliance Information	3
1.1	Conditions of Installation	4
1.2	Flue Terminal Position	5
1.3	Fireplace / surround suitability	6
1.4	Fire place opening / catchment space	6
1.5	Shelf Position	6
1.6	Installation Types	7-9
1.7	Hearths	9
1.8	Spillage Monitoring System	9
<b>Section 2</b>	<b>Installation of Fire</b>	
2.1	Unpacking the fire	10
2.2	Marking the Flue Pipe Opening	10
2.3	Marking the Fan Unit Recess on the Outer Wall & Fitting the fire box	11-17
2.4	Making the Electrical Connections	18
2.5	Gas tightness and Inlet pressure	19
<b>Section 3</b>	<b>Assembling Fuel Bed and Commissioning</b>	
3.1	Assembling the ceramics and fuel bed	20-24
3.2	Lighting the appliance	25
3.3	Checking for clearance of combustion products	26
<b>Section 4</b>	<b>Maintenance</b>	
4.1	Removal of the Burner Assembly	27
4.2	Removal of the Piezo Igniter	27
4.3	Removal of the Control Tap	28
4.4	Removal of the Thermocouple	28
4.5	Removal of the Solenoid	28-29
	Spare Parts Shortlist	29

This appliance is manufactured by :-

CFM Europe Ltd.  
Trentham Lakes,  
Stoke-on-Trent,  
ST4 4TJ

## SECTION 1

### INFORMATION AND REQUIREMENTS

#### 1.0 APPLIANCE INFORMATION

Model	FCPC14MN & FCPC26MN
Gas Type	G20
Main injectors (2 off)	Size 235
Pilot Type	S.I.T. Oxystop NG 9022
Max. Gross Heat Input :	6.5 kW
Min. Gross Heat Input :	4.2 kW
Cold Pressure :	20.0 +/-1.0 mbar
Ignition :	Push-button Piezo
Supply Voltage :	230V a.c.
Supply Frequency :	50 Hz
Supply Fuse :	3 Amp (Fixed Fused Spur) to BS 1362
IP Rating :	IP 44
Electrode Spark Gap :	4.0mm
Packed Weight :	14.5 kg (Black) 16.5 kg (Brass)
Fan Unit Packed Weight :	15 kg

#### Fire box Dimensions (with trim's fitted)

#### Warwick Models

Width :	(with standard trim, no spacer)	470mm
Height :	(with standard trim, no spacer)	586mm
Depth :	(overall-without fender)	155mm
Depth :	(overall-with spacer fitted)	105mm

Gas Connection : 8mm Compression (Supplied with fire)

## INSTALLATION REQUIREMENTS

### 1.1 CONDITIONS OF INSTALLATION

It is the law that all gas appliances are installed only by a CORGI Registered Installer, in accordance with these installation instructions and the Gas Safety (Installation and Use) Regulations 1998 as amended. Failure to install appliances correctly could lead to prosecution. It is in your own interest and that of safety to comply with the law.

The installation must also be in accordance with all relevant parts of the Local and National Building Regulations where appropriate, the Building Regulations (Scotland Consolidation) issued by the Scottish Development Department, and all applicable requirements of the following British Standard Code of Practice.

1. B.S. 5871 Part 3 Installation of Decorative Fuel Effect Gas Fires
2. B.S. 6891 Installation of Gas Pipework
3. B.S. 5440 Parts 1 & 2 Installation of Flues and Ventilation
4. B.S. 1251 Open fire place components
5. B.S. 6461 Part 1 Installation of Chimneys and flues
6. I.S. 813 : 1996 Domestic Gas Installation (Republic of Ireland)

**No purpose made additional ventilation is normally required for this appliance, when installed in G.B. When installing in I.E. please consult document I.S. 813 : 1996 Domestic Gas Installation, which is issued by the National Standards Authority of Ireland. If installing in Northern Ireland, please consult local building regulations. Any purpose made ventilation must be checked periodically to ensure that it is free from obstruction.**

## 1.2 FLUE TERMINAL POSITION

The minimum acceptable dimensions from the flue terminal to obstructions and ventilation openings are shown below in fig. 1 and listed in the table (fig. 2 below)  
**IT IS IMPORTANT THAT THE POSITION OF THE FLUE ALLOWS THE FREE PASSAGE OF AIR ACROSS IT AT ALL TIMES.**

Fig. 1




Fig. 2


DIMENSION	TERMINAL POSITION	MINIMUM DIMENSION
A	Directly below an opening, air brick, opening window	300mm (12 in.)
B	Above an opening, air brick, opening window	300mm (12 in.)
C	Horizontally to an opening, air brick, opening window etc.	300mm (12 in.)
D	Below gutters, soil pipes or drain pipes	75mm (3 in.)
E	Below eaves	200mm (8 in.)
F	Below balconies or car port roof	200mm (8 in.)
G	From a vertical drain pipe or soil pipe	150mm (6 in.)
H	From an internal or external corner	200mm (8 in.)
I	Above ground roof or balcony level	300mm (12 in.)
J	From a surface facing the terminal	600mm (24 in.)
K	From a terminal facing the terminal	1200mm (48 in.)
L	From an opening in the car port	1200mm (48 in.)
M	Vertically from a terminal on the same wall	1500mm (59 in.)
N	Horizontally from a terminal on the same Wall	300mm (12 in.)
O	From the wall on which the terminal is mounted	50mm (2 in.)
P	From a vertical structure on the roof	N/A
Q	Above intersection with roof	150mm

### 1.3 FIREPLACE / SURROUND SUITABILITY

The fire must only be installed on a hearth it must not be installed directly onto carpet or other combustible floor materials. The fire is suitable for fitting to non-combustible fire place surrounds and proprietary fire place surrounds with a temperature rating of at least 150°C. If a heating appliance is fitted directly against a wall without the use of a fire surround or fire place all combustible material must be removed from behind the trim. Soft wall coverings such as blown vinyl, wall paper etc. could be affected by the rising hot air and scorching and/or discoloration may result. Due consideration should be made to this when installing or decorating.

### 1.4 FIRE PLACE OPENING

The front opening of the fire place must be between 330 and 430 mm wide, and between 550 and 565mm high. If the opening exceeds these dimensions then a surround must be constructed from suitable non-combustible material to produce a correct size opening. Any surround must be suitably sealed to the fire place to prevent leakage. See below in fig.3



### 1.5 SHELF POSITION


The fire may be fitted below a combustible shelf providing there is a minimum distance of 200mm above the top of the fire and the shelf does not project more than 150mm. If the shelf overhangs more than 150mm the distance between the fire and the shelf must be increased by 15mm for every 25mm of additional overhang over 150mm.

## 1.6 INSTALLATION TYPES

This fire can be fitted against an outside facing flat wall surface or into a fireplace opening cut into the wall.


**When fitting the fire in front of the inner cavity wall,** the distance between the mounting face of the fire and the rear face of the firebox must be a minimum of 170mm, a false chimney breast or fireplace surround should be constructed. The firebox must then be secured into the fireplace using the method described in section 2. Any combustible material must be removed from the area around the firebox flange. In all installations, ensure that there is no structural damage to the property or the damp course. See fig. 4 below

**Fig. 4**



**When fitting the fire into a cavity wall,** this requires the opening of the inner leaf of brickwork, to recess the firebox into. The opening needs to be sufficient to accommodate the firebox. To support the wall above the hole, a suitable lintel must be inserted across the top of the opening. If fitting the appliance into a cavity wall, a lintel 750mm long having a thickness of 75mm with a height of the inner wall should be used. The lintel could be either pre-cast concrete or steel - Catnic CN52 or CN 46 could be used, depending upon the inner wall thickness. Before proceeding with the installation of the fire, an assessment of the area immediately above the fire is required, see Fig. 5 overpage. If there is no existing openings within either triangle, proceed with forming the opening. However, if opening or beams occur within either triangle, then you should seek specialist advice from a structural engineer or consider relocating the proposed position of the firebox.


**Fig. 5**



**To proceed with the installation when the above stated criteria have been satisfied :-**

Mark out where possible, centrally beneath a block joint where the lintel is to be fitted. Unless lime mortar has been used it will be necessary to drill four holes with a masonry drill, then use a mechanical cutter such as a "shark saw" to cut out the correct size of slot in the inner leaf of brickwork for the lintel you have chosen to install. See fig. 6 below.

**Fig. 6**




Fit the lintel, ensure that it is bedded on mortar. Do not bed on a dry bed. Then remove all debris from the cavity and construct the opening to the minimum / maximum opening sizes as shown overpage (fig. 7) and in section 1.4, (fig. 3)



Remove any combustible material from within the area of the opening. No combustible material can be allowed to come into contact with any area of the appliance.

**Fig. 7**



### **1.7 HEARTHES**

This appliance must only be installed on to a concrete or non-combustible hearth. The hearth material must be a minimum thickness of 12mm with the top surface at least 50mm above the floor. The hearth must be fitted symmetrically about the fire opening and have a minimum width of 760mm and a minimum projection of 300mm forwards from the fire opening.

### **1.8 SPILLAGE MONITORING SYSTEM**

This appliance is fitted with an atmosphere sensing spillage monitoring system in the form of an oxygen sensing burner. This is designed to shut the fire off in the event of a partial or complete blockage of the flue causing a build up of combustion products in the room in which the fire is operated. **The following are important warnings relating to this spillage monitoring system :-**

- 1) The spillage monitoring system must not be adjusted by the installer.
- 2) The spillage monitoring system must not be put out of operation.
- 3) When the spillage monitoring system is exchanged only a complete original manufacturers part may be fitted.

## SECTION 2 INSTALLATION OF FIRE

### 2.1 UNPACKING THE FIRE

Carefully lift the fire out of the carton. Remove the loose item packaging carefully from the front of the appliance. Check the contents as listed :-

#### Packing Check List - All Models


1off	Fire box / burner assembly,
1off	Boxed fuelbed base, fuelbed insulation mat, 2 piece ceramic front rail, and 1 piece fuelbed overlay, bag of 22 synthetic coals (packed in fuel-bed box)
1off	Fret & Ashpan (boxed), 1off Trim
1off	Loose items bag.
1off	Installation & Maintenance Instruction Book, 1off User Instruction Book
1off	Rope Seal (packed in fan unit - Pack 2 of 2)
1off	Boxed Fan Unit & Flue Pipe (Pack 2 of 2)

### 2.2 MARKING THE FLUE PIPE OPENING ON THE WALL (ALL MODELS)

Drill a pilot hole into the outer leaf of brickwork at a height of 490mm from the hearth level, centrally about the firebox, then create a square hole 100mm / 4 inch vertically central to the centre line of the appliance. See fig. 8 below.


**NOTE :** If the fire is to be fitted against the inner cavity wall, the inner and outer cavity walls will require the 100mm / 4 inch hole creating

Fig. 8




### 2.3 MARKING THE FAN UNIT RECESS ON THE OUTER WALL (ALL MODELS)

Fig. 9



- a) **The recess and mounting holes as detailed above will require cutting into the outer cavity of the wall to accept the fan unit cast iron body.**
- b) To proceed with the installation, take the flue pipe (380mm in length) and secure to the firebox as shown below in Fig. 10, with the 3 off fixing screws supplied.

Fig. 10




- c) Carefully place the firebox and flue pipe together into the builders opening and allow the flue pipe to protrude through the hole in the outer cavity wall.

- d) Mark the flue pipe in line with the flue spigot so that it can be cut to length.

NOTE :- When cutting the flue pipe to length, allowance for the rebate on the fire surround used or false chimney breast constructed must be taken into account.


- e) The cover of the fan unit must now be removed to proceed with the installation. Remove the four off screws as shown below in Fig. 11

**Fig. 11**



- f) Remove the 2 off screws for the electronic control board mounting plate as shown below in Fig. 12


**Fig. 12**



- f) With the fan cover removed, disconnect the air pressure switch tubes from the outlet venturi as shown below in Fig. 13, ensuring that you make a note of their location for when you re-fit them.

**Fig. 13**


Removing pipes  
from the air  
pressure switch



**NOTE : If you re-fit the air pressure switch tubes the wrong way around, the appliance will not operate as a positive flue pressure cannot be generated, and hence the gas solenoid valve will not open.**


- g) With the electronic control board mounting plate tilted forward, disconnect the positive, negative and earth wires from the fan unit as shown below in Fig. 14, ensuring that you make a note of their position for when you re-fit them.

**Fig. 14**




- h) Remove the 3 off fan mounting plate screws as shown overpage in Fig. 15

**Fig. 15**



- i) Remove the firebox and flue pipe assembly from the false chimney breast or fire surround as applicable. Run the gas supply in from the right hand side of the firebox as shown below in Fig. 16

**Fig. 16**




- j) Screw the cast iron fan unit housing to the outer cavity wall, using the screws and rawlplugs supplied.
- k) **The preferred method of fixing the firebox into place which is suitable for almost all situations is the cable fixing method which is described in the following section in detail.**

To fit using the **preferred** cable method proceed as follows-

- l) Mark out and drill 4 off No 14 (6mm) holes in the back face of the fire opening (inner face of the outer cavity wall in most instances) in the positions shown below in fig. 17

**Fig. 17**




Fit the wallplugs provided and screw the fixing eyes securely into the rear of the fire opening. If the clearance at the rear of the fire is at the minimum specified for a powerflue application, it may be necessary to bend over the lower fixing eyes after screwing them fully in to the rear of the outer cavity wall inner face.

**Proceed as follows to remove the burner assembly from the firebox :-**


- m) Remove the trim. Remove the burner heat shield from the front of the fire box to allow access to the burner, as shown below in fig. 18

**Fig. 18**




- i) Remove the four retaining screws securing the burner to the firebox. The base of the burner unit can now be pulled forward, allowing the burner to be removed from the fire box. See fig. 19 overpage

Fig. 19



- m) Uncoil the two fire fixing cables and thread one end of each of the cables through one of the two holes on each side of the flue outlet shroud. **Electrical Wiring Loom** - Bring the 5 core cable from the fire box (with small 6 way plug attached) through the cable entry hole in the cast iron fan unit body, and secure to the wall plate with the strain relief bush, allowing at 150mm / 6 inches of wire to protrude into the wall plate.
- n) Position the fire carefully on the (protected) surface of the hearth and reach into the fire opening. Thread each of the cables vertically downwards through the pair of fixing eyes on the same side of the fire. Thread the free end of the cables through the corresponding circular hole on each side of the lower rear of the fire. Carefully slide the fire box back into the fire opening and pull both cables tight.
- o) Thread a tensioning screw over each of the cables and ensure that the tensioning nut is screwed fully up against the hexagon shoulder of the tensioning screw (this provides maximum travel for the tensioning nut).
- p) Fit a screwed nipple on to each of the cables and pull hand tight up against the tensioning screw, then secure each nipple with a flat bladed screwdriver. See fig. 20 below


Fig. 20





- q) Evenly tighten the tensioning nuts to tension both cables and pull the fire snugly against the wall. Do not overtighten, it is only necessary to pull the seal up against the sealing face of the wall, it does not need to be compressed. Check that there are no gaps behind the seal.
- r) With the fire securely in place, if a concealed gas connection has been made through the access holes in the R/H side of the fire, the hole should be closed around the pipe to prevent leakage of air through the gap around the pipe.
- s) Connect the gas supply pipe to the solenoid valve on the burner assembly, and carry out a gas tightness test up to the isolation valve, which is attached to the solenoid valve pipe.
- t) Refit the burner. Fit the four retaining screws and check that the burner is correctly locked into position. Before making the final gas connection to the solenoid valve, thoroughly purge the gas supply pipework to remove all foreign matter, otherwise serious damage may be caused to the gas control valve on the fire. Ensure correct orientation of the restrictor valve behind the burner is obtained  
**NOTE :- Failure to correctly purge the pipework will invalidate the guarantee**
- u) It is now necessary to fit the rope seal between the spigot on the fan unit cast iron body and the flue pipe, as shown below in Fig. 21

**Fig. 21**




- w) Proceed to section 2.4 to make the electrical wiring connection

## 2.4 MAKING THE ELECTRICAL CONNECTION.

**WARNING :** THIS APPLIANCE MUST BE EARTHED AND MUST BE CONNECTED VIA A 3 AMP FIXED FUSED SPUR WITH A MINIMUM CONTACT SEPARATION OF 3MM - DO NOT UNDER ANY CIRCUMSTANCES CONNECT TO A 13AMP TYPE PLUG AND SOCKET

- a) Whilst feeding the 5 core cable through the cable entry hole in the fan unit, press the fan unit into the wall plate until it engages securely. Fix in position with the screws provided.
- b) Connect the 6 way miniature plug into the 6 way socket emerging from the circuit board, as shown below in Fig. 22

**Fig. 22**



- c) Connect the earth wire from the wiring loom onto the fan enclosure earth point as shown above in Fig. 22
- d) Re-fit the painted fan box cover and secure with the screws provided.

## 2.5 GAS TIGHTNESS AND INLET PRESSURE


- a) Remove the pressure test point screw from the inlet elbow and fit a manometer.
- b) Turn on the main gas supply and carry out a gas tightness test.
- c) Depress and hold the green “on” button on the fan control panel, located at the right hand side of the fire (when viewed from the front). The fan unit will operate, and when the air pressure switch (located inside the fan unit) detects sufficient air flow within the flue, an audible click will be heard and the gas solenoid valve will open, this will be indicated by the green light illuminating .
- d) Continue to hold-in the control knob and press the igniter button. If the burner does not light, continue to press the igniter button until ignition occurs. Continue to hold the control knob for a minimum of 10 seconds to allow the thermocouple to heat up, if the burner goes out when the control knob is released, repeat the lighting sequence.
- e) Check that the gas pressure is **20.0 mbar (+/- 1.0mbar) 8.0 in w.g. (+/- 0.4 in w.g.)**
- f) After removing the manometer, ensure that the pressure test point screw is checked for gas tightness with suitable leak detection spray or fluid.

**SECTION 3  
ASSEMBLING FUEL BED AND COMMISSIONING**

**3.1 ASSEMBLING THE CERAMICS AND FUEL BED**


- a) Place the insulation mat centrally on to the fuelbed support then place the ribbed hard ceramic fuelbed base on top of the mat and pull both fully forwards to the burner. **Make sure that the fuelbed base is located centrally in the fire box. Ensure that both the mat and fuelbed base fit fully down onto the fuel bed support and are not lodged on the burner. See fig. 23 & 24 below.**

**Fig. 23**




**Fig. 24**

Side view showing fuelbed incorrectly positioned on burner skin



Side view showing fuelbed correctly located behind burner



- b) Position upper fuelbed component on to the locating pegs on the top of the fuelbed base, ensuring that it is correctly seated as shown below in fig. 25

**Fig. 25**



- c) Fit the two parts of the ceramic front coal support on to the front support bracket, ensuring they are correctly located, as shown below in fig. 26

**Fig. 26**



- d) Select seven of the coals and arrange along the front ceramic coal support using the shallow depressions as guidance for the coal position. See fig. 27 below

**Fig. 27**



- e) Select the four coals and arrange along the front of the fuelbed, directly behind the front row of coals. Leave gaps between the coals in line with the front flame notches on the front of the fuelbed (shown below arrowed), this enhances the front flames and provides the most pleasing flame effect. Select the two **smallest** coals and place them at each end of the second row of coals. See fig. 28 below.

**Fig. 28**



- f) Select five of the coals and arrange along the fuelbed behind the second row of coals spacing them evenly and positioning them as shown below in fig. 29.

**Fig. 29**



- g) Select the remaining four coals and position to fill the gaps left at the top rear of the fuelbed. The coals will locate naturally into the depressions in the top rear of the fuelbed. See below fig. 30 below.

**Fig. 30**



The exact position and fit of the coals may be finely adjusted to give the most pleasing and random appearance.

**This appliance uses fuel effect pieces containing Refractory Ceramic Fibres (R.C.F.), which are man-made vitreous silicate fibres. Excessive exposure to these materials may cause temporary irritation to eyes, skin and respiratory tract. Consequently, it makes sense to take care when handling these articles to ensure that the release of dust is kept to a minimum. To ensure that the release of fibres from these R.C.F. articles is kept to a minimum, during installation & servicing we recommend that you use a HEPA filtered vacuum to remove any dust and soot accumulated in and around the fire, before and after working on the fire. When replacing these articles we recommend that the replaced items are not broken up, but are sealed within a heavy duty polythene bag, clearly labelled as "RCF waste". This is not classified as "hazardous waste" and may be disposed of at a tipping site licensed for the disposal of industrial waste. Protective clothing is not required when handling these articles, but we do recommend you follow the normal hygiene rules of not smoking, eating or drinking in the work area, and always wash your hands before eating or drinking. This appliance does not contain any component manufactured from asbestos or asbestos related products.**



### 3.2 LIGHTING THE APPLIANCE (ALL MODELS)

- a) Turn on the gas isolation tap.
- b) Depress and hold the green “on” button on the fan control panel, located at the right hand side of the fire (when viewed from the front). The fan unit will operate, and when the air pressure switch (located inside the fan unit) detects sufficient air flow within the flue, an audible click will be heard and the gas solenoid valve will open, this will be indicated by the green light illuminating .
- c) Depress the control knob and turn anti-clockwise to the position marked ignition / low rate. Hold in the control knob for a few seconds to purge the pipe work.
- d) Continue to hold-in the control knob and press the igniter button. If the burner does not light, continue to press the igniter button until ignition occurs. Continue to hold the control knob for a minimum of 10 seconds to allow the thermocouple to heat up, if the burner goes out when the control knob is released, repeat the lighting sequence.
- e) Turn the control knob in the anti-clockwise direction to the high position and the gas rate will increase to high rate (6.5 kW)
- f) Turn the control knob clockwise to the low position and the gas input will be reduced to the minimum setting (2.5 kW)
- g) Slightly depress the control knob and turn to the off position, the burner will now be extinguished.

**WARNING :** If the fire goes out for any reason or is turned off and it is necessary to re-light the fire it is important to allow the fire to cool for 3 minutes before attempting to re-light it.

### 3.3 CHECKING FOR CLEARANCE OF COMBUSTION PRODUCTS (ALL MODELS)

- a) Close all doors and windows in the room.
- b) Light the fire and allow to run for approximately 5 minutes on high position.
- c) After approximately 5 minutes hold a smoke match just inside and below the centre of the lower front edge of the top of the fire. (It is recommended that a suitable smoke match holder is used when checking for clearance of combustion products). All smoke generated should be drawn back into the flue. If slight spillage occurs or if in doubt, repeat the test after a further 5-10 minutes.

**If the test indicates that spillage is occurring, check that the supply voltage to the appliance is 230V (+/- 5%). If the supply voltage is outside these parameters, this could be causing the appliance to spill. Obtain the correct supply voltage and re-test the appliance from cold.**

- d) If spillage persists, the fan unit is not functioning correctly and a fault exists. If, after investigation the fault cannot be traced and rectified, the fire must be disconnected from the gas supply and expert advice obtained from the manufacturer.
- e) If there is an extractor fan fitted anywhere in the vicinity of the appliance, the spillage test should be repeated with the fan running on maximum and all interconnecting doors open.
- f) After ensuring that the fire is safe to use it should be left on high position to fully warm up. During this time a slight odour may be noticed, this is due to the "newness" of the fire and will soon disappear.

At this stage any minor adjustments to the coals should be made using suitable long handled tongs and taking care not to damage the coals.

Finally, hand the Installation and Maintenance Instructions and the Users Instructions over to the customer and explain the operation of the fire.

## **SECTION 4 MAINTENANCE**

### **Servicing Notes**

Servicing should be carried out annually by a competent person such as a CORGI registered engineer. **This is a condition of the Flavel guarantee schemes.** The service should include visually checking the chimney and fire opening for accumulations of debris and a smoke test to check for a positive up-draught in the chimney.

The condition of the coals should be checked and **if necessary the whole set should be replaced with a genuine replacement set.**

The burner assembly is designed to be removed as a complete unit for ease of access. **After any servicing work a gas tightness check must always be carried out.**

### **For Diagrams refer to Section 2**

#### **4.1 Removing the burner assembly from the fire.**

- 4.1.1 Prepare work area (lay down dust sheets etc.)
- 4.1.2 Lift the trim and ash pan cover / fret out of the way and put them in a safe location. Remove the loose coals from the fuel bed. Remove the front ceramic from the rail. Unscrew the two pozi-driv fixing screws which secure the burner heat shield and remove it from the fire.
- 4.1.3 Isolate the gas supply at the valve behind the burner assembly, accessible through over the on / off switch at the RHS. Remove the inlet pipe from the appliance inlet elbow. Unscrew and remove the four screws which retain the burner. Remove the burner assembly from the fire. Disconnect the two leads from the on / off switch.
- 4.1.4 To refit the burner assembly. Re-connect the on / off switch wires (in any order). Push the base of the control panel fully into the fire and secure with the four screws. Refit the gas supply pipe and carry out a gas tightness test. Refit the burner heat shield then refit the fuelbed referring to section 3.1 for the correct layout. The trim and fret / ash pan cover can now be re-positioned.

#### **4.2 Removing the Piezo Igniter (All models).**

- 4.2.1 Isolate the appliance from the gas and electricity supply.
- 4.2.2 Remove the burner assembly as in section 4.1

- 4.2.3 Disconnect the ignition lead from the piezo and unscrew the retaining nut on the rear of the control panel. Withdraw the piezo from the front of the control panel. Re-assemble in reverse order and carry out a gas tightness test. Ensure the heatshield is re-fitted.

#### **4.3 Removing the Control Tap from the fire.**

- 4.3.1 Remove the burner assembly as in section 4.1.
- 4.3.2 Pull the control knob off the control tap spindle.
- 4.3.3 Loosen and remove the three gas pipe retaining nuts from the control tap and release the ends of the gas pipes from the control tap body. Loosen and remove the thermocouple securing nut from the end of the control tap.
- 4.3.4 Unscrew the control tap locknut from the front of the control panel and remove the control tap.
- 4.3.5 To refit a control tap, reassemble in reverse order noting that the control tap locates with a flat in the control panel. Carry out a gas tightness test after re-assembly.

#### **4.4 Removing the Oxy-Pilot Assembly**

**Note : Because this appliance is fitted with an atmosphere sensing 'Oxy-Pilot' it is not possible to replace the thermocouple separately, because the thermocouple position is factory set to a tight tolerance. Any replacement of parts on the pilot requires a complete new pilot assembly.**

- 4.4.1 Remove the burner assembly as in section 4.1
- 4.4.2 Unscrew and remove the thermocouple retaining nut from the end of the control tap and disconnect the ignition lead from the pilot electrode.
- 4.4.3 Unscrew and remove the two pozi-driv screws which secure the pilot assembly to the burner. Remove the pilot.
- 4.4.4 Re-assemble in reverse order and carry out a gas tightness test.

#### **4.5 Removing the Solenoid Valve (All models).**

- 4.5.1 Isolate the appliance from the gas and electricity supply.
- 4.5.2 Remove the burner assembly as described in section 4.1
- 4.5.3 Disconnect the solenoid plug from the harness.

4.5.4 Remove solenoid from pipe and refit new solenoid.

#### **PARTS SHORTLIST**

Replacement of any other parts must be carried out by a competent person such as a CORGI registered gas installer. The part numbers of the main replaceable parts are as follows, these are available from your local Flavel dealer, whose details can be found on the CFM Europe website in the “stockist” section . (see rear page for contact details)

Pressure Switch	GC-4209
Solenoid Valve	GC-4123
Fan Motor	50-35860
Circuit Board (Supplied with Wiring Harness)	GC-4221
Coal fuelbed base	20-16840
Coal fuelbed front rails (L/H & R/H Pair)	20-17280
Coal fuelbed overlay	20-16850
Replacement coal set	20-16860
Gas Valve	B-36990
Piezo Igniter	B-1320
Ignition Wire	B-14340

**Due to our policy of continual improvement and development the exact accuracy of illustrations and descriptions contained in this book cannot be guaranteed**

**Part No. B-80080  
Issue 2**



CFM Europe Ltd.  
Trentham Lakes  
Stoke-on-Trent  
Staffordshire  
ST4 4TJ

[www.cfm-europe.com](http://www.cfm-europe.com)

**Telephone - General Enquiries : (01782) 339000**  
**Telephone - Service : (08700) 101187**



















