


**Connection of the Atmos MonoSolar hot water thermal store to the Atmos InterCombi HE32 condensing gas combi boiler.**



**IMPORTANT**  
The Duco mixing valves must be connected as shown. Take care.

Non Adjustable Duco thermostatic mixing valve

Hot Out Ts

Ts < 55 deg C

Ts > 55

Adjustable Duco thermostatic mixing valve with black knob

Hot water supply (blended)

Cold mains water supply



Copyright Atmos Heating Systems, West March, Daventry, Northants NN11 4SA Tel; 01327 871990 April 2005