




FERROLI


OPTIMA 201


- LISTA PEZZI DI RICAMBIO
- SPARE PART LIST
- ERSATZSTEILE
- LISTE PIECES DETACHES
- LISTA PIEZAS DE REPUESTO



Appr. nr. B94.05 T - CE 0063 AQ 2150







FERROLI	OPTIMA 201	DATE:1.11.99
----------------	-------------------	---------------------

KEY	G.C.No:	Description	ITALIAN	ENGLISH
			Code No:	Code No:
1	E27-653	Panel - Bottom Panel	3113293/0	802110
2	E27-654	Panel - Upper Front Panel	3113994/0	819940
3	E27-655	Drop - Down Complete	3113996/0	810996
4	-	Drop - Down Complete	3113997/0	See 3
5	372-342	Panel - Side Panel (Reversible Side)	3114008/0	800680
6	-	Bracket - Bracket for Burner Bar (Not Required)	3120617/0	See 11
7	372-337	Bracket - Expansion Vessel Bracket	3120621/0	816150
8	-	Plate - Thermostat 100 Degree Flue Bracket (See 96)	3120640/0	See 96
10	372-307	Electric Support Box	3120766/0	817500
11	372-172	Burner Bar c/w Bracket	3120842/0	817900
12	372-129	Combustion Chamber - Bottom Burner Box	3200218/0	810880
13	372-132	Spy Hole Flap for Pilot	3211171/1	811710
14	372-131	Flap - Cover Plate for Pilot	3211269/0	813690
14a	372-352	Collar - Flue Pipe to Draught Diverter	3211336/0	814050
15	372-354	Cover - Draught Diverter Cover	3211369/0	812680
16	372-258	Frame - Burner Frame	3290805/0	818050
17	372-350	Combustion Chamber Support	3290808/0	814040
19	372-232	Pressure Test Point	3340028/0	810280
20	-	Nut - Pilot Burner Pipe (Not Required)	3340085/0	See 40
21	372-250	Gasket - 1/4"inch	3370038/1	810380
22	372-325	Gasket - 1/2"inch	3370040/1	810850
23	372-196	Gasket - 3/4"inch	3370041/1	810710
24	372-259	Gasket - Injector 15mm (Copper Gasket)	3370048/0	810480
25	372-142	Gasket - 3/8"inch	3370053/0	810690
26	386-573	Injector - Pilot Injector (NG)	3370057/0	810570
26	E06-331	Injector - Pilot injector (LPG)	3370066/0	810660
27	E03-312	Injector - Injector Main (LPG)	3400566/0	815870
27	372-176	Injector - Injector Main (NG)	3400585/0	815850
28	372-146	Plug - Female 1/2"inch Plug	3400732/0	817320
29	372-193	Nut - Ring Nut 3/4"inch	3400743/0	817430
30	372-192	Nut - Ring Nut 1/2"inch	3400788/0	817880
31	372-147	Cold Water Filter (1/2"inch)	3400808/0	800240
32	372-192	Nut - 1/2"inch	3400839/0	817880
33	372-193	Nut - 3/4"inch	3400840/0	817430
34	372-151	Cap - Cap for Air Vent	3400855/0	818550
35	372-150	Sphere - Sphere for Air Vent	3400856/0	818560
36	-	Nipple - 1/2"inch (Not Required)	3400863/0	-
37	-	Nipple - 3/4"inch (Not Required)	3400864/0	-
38	297-091	Hinge - (Right Handed)	3410052/0	810052
39	297-090	Hinge - (Left Handed)	3410053/0	810053
40	372-357	Pipe - Pilot Burner Pipe "Aluminium"	3422131/0	813310
41	-	Spring - Spring for Spy Hole Flap (Not Required)	3430028/0	See 14
42	372-170	Spring - Smoke Chamber Fixing Spring	3440303/0	813030
43	372-325	Washer - 1/2"inch	3450437/0	810850
44	372-196	Washer - 3/4"inch	3450438/0	810710
45	-	Ring - Stop Ring 1/2"inch (Not Required)	3450439/0	-
46	-	Ring - Stop Ring 3/4"inch (Not Required)	3450440/0	-
47	372-219	Knob - Thermostatic Knob (Central Heating)	3500180/0	811940

FERROLI	OPTIMA 201	DATE:1.11.99
----------------	-------------------	---------------------

KEY	G.C.No:	Description	ITALIAN	ENGLISH
			Code No:	Code No:
48	372-290	Knob - Extension Knob (Gas Valve)	3500184/0	811840
51	-	Insert - Stencilled Insert (Not Required)	3500596/1	See 52
52	E04-499	Fan Assembly	3500571/0	803860
53	372-153	Gasket - 1 1/2" inch	3510016/0	810160
54	372-313	Gasket - Pump Gasket (45mm)	3510034/2	810090
55	-	O-Ring 3043 (Not Required)	3510042/0	-
56	E05-948	O-Ring 3062	3510043/0	806043
57	372-180	O-Ring 3087	3510050/0	810500
58	372-125	Insulation - Combustion Chamber "Rear"	3531403/0	814030
59	297-028	Sight Glass 50 x 30 x 3.3	3531525/0	815250
60	372-124	Insulation - Combustion Chamber "Side"	3531528/3	815280
61	372-135	Insulation - Combustion Chamber Cover	3531530/0	815300
62	372-225	Selector Switch	3610030/0	801230
63	E03-349	Pressure Gauge	3640074/0	801870
64	386-577	Thermostat 88 Degree (Central Heating)	3640128/0	800160
65	386-828	Thermostat - Frost Thermostat	3640139/0	800180
66	386-815	Thermostat - 100 Degree (Overheat)	3640170/0	801240
67	372-224	Thermostat - Boiler Thermostat c/w Plug	3640172/0	801260
68	386-577	Thermostat 88 Degree (Flue Gas Thermostat)	3640177/0	800160
69	E03-340	Flow Meter	3640186/0	803430
70	372-228	Terminal Block (2 Stud)	3650109/0	814460
71	372-160	Terminal Block (3 Stud)	3650387/0	813870
71a	379-815	Clock - Clock 24 Hour LCD	3650476/0	803840
72	408-780	Grommet	3650486/0	814860
73	372-304	Electric Box	3650498/0	812820
74	372-301	Cover - Electric Box Cover	3650499/0	818840
75	372-302	Cover - Connector Box Cover	3650501/0	817530
76	386-814	Pump - Grunfos UPS 15-50 x 18 9K	3660073/0	800600
76	386-814	Pump - Grunfos UPS 15-50 x 18 9K	3660108/0	800600
79	372-309	Spark Generator	3670194/0	801150
81	379-954	Thermocoupler - Honeywell Q309A 3273	3670207/0	801170
82	386-586	Pilot Assembly	3670218/0	800270
83	386-575	Electrode - Spark Electrode	3670219/0	800280
84	386-821	Expansion Vessel - 7 Litre Zilmel Type 387	3680176/0	811770
86	E03-313	Gas Valve - VR4600N	3680252/0	803450
87	E05-970	Modureg , Complete	3680254/0	818289
88	386-816	Safety Valve (3 Bar)	3690066/0	800130
89	394-246	Automatic Air Vent	3690088/0	801160
90	379-987	Flow Limiter - 7 Litres	3690127/0	801250
92	372-335	Frame - Boiler Support Frame	3710448/0	813480
93	372-351	Combustion Chamber , Complete	3740089/0	810890
94	372-353	Heat Exchanger , Complete	3740090/1	800450
95	372-134	Cover- Combustion Chamber Cover	3740091/0	810910
96	372-355	Draught Diverter	3751143/0	800650
97	372-171	Burner Bar	3760709/0	817090
99	372-358	High Limit Wire (ECO Split Wire)	3830749/0	817490
102	386-818	Sensor - DHW & Central Heating (Phillips KTY 81-110)	3831030/7	800310
103	372-320	Microswitch , Complete	3831024/0	801370

